

HP Barrel Band for the Umarex Gauntlet 2

The PCP should be degassed when the band is first installed so that the bottle and the drop block are relaxed which will minimize forcing the band on which may lift or pull down the barrel shroud. When you install the barrel band for the first time be sure the band screw(s) are loose to allow installation.

I have videos where I discuss how the bottle drop block can force the HP Barrel Band to push up or pull down on the barrel and cause POI shift that may be impossible to compensate for in scope turret adjustments. The below link/QR code will bring you directly to the point in a video where I explain how the bottle drop block angle can cause this POI shift issue. I also show how a simple adjustment can overcome this shift issue.

<https://tinyurl.com/bandflex>



Once the band is on the bottle, be sure to only tighten the screw(s) do not crank on them. If you hear cracking **STOP** that's too tight! Firm not 50 foot-pounds of torque. Once the band is on and tight, fill your PCP like normal.

Thank you

Hajimoto



HajimotoProductions.Com

Hajimoto@HajimotoProductions.com